

Instruction manual for AU10 PLB

Arming the PLB



Lift the RESTRAINER TAB up over the ARMING SWITCH.



Slide the ARMING SWITCH down to the [READY] position until it clicks into place and ensure the RESTRAINER TAB is positioned in the gap above the ARMING SWITCH.

Disarming the PLB



Slide the ARMING SWITCH up to the off position and then lift and pull the RESTRAINER TAB down over the ARMING SWITCH

OFFSHORE AU10 PLB Checks

- Ensure the PLB arming switch is in the OFF position. (rubber band under the switch)
- Press the activation button for 1 second to activate test mode
- There will be short audible beeps from the PLB approx. 1 second intervals
- Press the activation button again to cancel test mode
- Finally, Place the arming switch back to the 'Armed' position. (Rubber band at the top of the switch)

Key Differences to the user

When the AU10-HT is in the "READY" or armed position the unit will beep once every 60 seconds to indicate the units are armed and ready for operation.

However, if you can hear a double beep every 60 seconds, this may indicate low battery.

When stored offshore we would recommend disarming the PLBs after use, and re-arming them prior to donning the lifejacket.



VIKING LIFE-SAVING EQUIPMENT
- Protecting people and business